

1) Roll your Shape Station into its desired location



2) Flip down the surface by pulling the lever located under the surface in the middle



3) Roll the station to its final position and lock the wheels

